Operating Instructions for Skydancer 3m



Dirk Joachimsmeier

Tel: 02 91 90 24 691 **Fax:** 02 91 90 24 799 **Mobil:** 01 70 33 00 300

dirk.joachimsmeier@airlebniswelt.com

airlebniswelt GbR

Schützenstraße 50 • 59872 Meschede Tel: 02 91 90 24 691 • Fax: 02 91 90 24 799 info@airlebniswelt.com www.airlebniswelt.com

Geschäftsführer:

Dominik Stracke • Dirk Joachimsmeier Steuernr: 334 5701 0624 • FA Meschede

Sparkasse Meschede Kto: 466 49 BLZ 464 510 12

Please read these instructions carefully before setting up the display.

These instructions are part of the sales contract between the customer and airlebniswelt GbR.

Description of function:


This inflatable is a moving display with a height of 3m, which is set up with two fans. The fans are mounted in a case. The changing pressure in the inflatable creates the movement of the Skydancer.

Place of installation:

The area of operation needs to be a horizontal place of 1m². Remove this area from dirt and light items, which can be absorbed by the fan and destroy the fan. These items can also change the color of the inflatable. To avoid damages and soiling of the inflatable, make sure that in the radius (Hmax) of the Skydancer are no power supply lines, pylons, chimneys, guttering, traffic signs, as well as oily, sharp edged or dirty objects.

Installation:

- 1.) Set up case on a dry and horizontal area
- 2.) Remove the cover
- 3.) Remove area from dirt and light items
- 4.) Visual check on fans
- 5.) Fasten the Velcro of the Skydancer on the fans
- 6.) Connect fans to 220V power



- 1. Movement of the Skydancer
- 2. Risk of damage of the Skydancer

The buyer is responsible for the safety of the people around. The buyer is responsible for any permits necessary for the usage of the Skydancer.

Conditions of service:

Ideal results are in non-windy weather. The usage of the Skydancer is allowed when it is barely windy and lightly raining. The usage of the inflatable is not allowed if the conditions are rough (wind and rain).

